


MANIPULAČNÍ SMYČKY

SMYČKY S OKY



	WLL*	0.8 WLL	2 WLL	1.4 WLL	1 WLL
0.5 t	500	400	1000	700	500
1 t	1000	800	2000	1400	1000
2 t	2000	1600	4000	2800	2000
3 t	3000	2400	6000	4200	3000
4 t	4000	3200	8000	5600	4000
5 t	5000	4000	10000	7000	5000
6 t	6000	4800	12000	8400	6000
8 t	8000	6400	16000	11200	8000
10 t	10000	8000	20000	14000	10000
12 t	12000	9600	24000	16800	12000
15 t	15000	12000	30000	21000	15000
20 t	20000	16000	40000	28000	20000

	1 m	2 m	3 m	4 m
1 t	XPSPW01L01	XPSPW01L02	XPSPW01L03	XPSPW01L04
2 t	XPSPW02L01	XPSPW02L02	XPSPW02L03	XPSPW02L04
3 t	XPSPW03L01	XPSPW03L02	XPSPW03L03	XPSPW03L04
4 t		XPSPW04L02	XPSPW04L03	XPSPW04L04
5 t		XPSPW05L02	XPSPW05L03	XPSPW05L04
6 t		XPSPW06L02	XPSPW06L03	XPSPW06L04
8 t		XPSPW08L02	XPSPW08L03	XPSPW08L04
10 t		XPSPW10L02	XPSPW10L03	XPSPW10L04
12 t			XPSPW12L03	XPSPW12L04
15 t			XPSPW15L03	XPSPW15L04
20 t			XPSPW20L03	XPSPW20L04

	5 m	6 m	8 m	10 m
1 t	XPSPW01L05	XPSPW01L06	XPSPW01L08	XPSPW01L10
2 t	XPSPW02L05	XPSPW02L06	XPSPW02L08	XPSPW02L10
3 t	XPSPW03L05	XPSPW03L06	XPSPW03L08	XPSPW03L10
4 t	XPSPW04L05	XPSPW04L06	XPSPW04L08	XPSPW04L10
5 t	XPSPW05L05	XPSPW05L06	XPSPW05L08	XPSPW05L10
6 t	XPSPW06L05	XPSPW06L06	XPSPW06L08	XPSPW06L10
8 t	XPSPW08L05	XPSPW08L06	XPSPW08L08	XPSPW08L10
10 t	XPSPW10L05	XPSPW10L06	XPSPW10L08	XPSPW10L10
12 t	XPSPW12L05	XPSPW12L06	XPSPW12L08	XPSPW12L10
15 t	XPSPW15L05	XPSPW15L06	XPSPW15L08	XPSPW15L10
20 t	XPSPW20L05	XPSPW20L06	XPSPW20L08	XPSPW20L10

*WLL - pracovní limit zátěže [t]